DR Technologies, Strategies and Case Studies

March 3, 2011

Mary Ann Piette, Sila Kiliccote, Dave Watson, Rish Ghatikar

Research Director, DRRC

Deputy, Building Technologies Department

Staff Scientist, LBNL

MAPiette@lbl.gov





Concepts and Terminology Levels of Automation in DR


- Manual DR Building operators manually turn off switches and change set points at each device
 - Labor intensive
 - Poor reliability, repeatability
 - Day ahead notification req'd
- Semi-Automated DR pre-programmed DR strategies initiated by a person via centralized control system
 - Better reliability, repeatability
 - Hours ahead notification req'd
- Fully-Automated DR pre-programmed DR strategies automatically initiated upon receipt of remote signal
 - Most reliable & repeatable
 - Sheds can occur within seconds

HVAC - Global Temperature Adjustment

- GTA based DR strategies can be used:
 - Manually by building operators
 - Automatically based on remote signals
- GTA Signal from central EMCS server to all space temperature controllers throughout the facility.
- GTA well suited for HVAC equipment such as:
 - VAV boxes
 - Fan coil units
 - CAV multi-zone temperature control valves
 - heat pumps & DX package units.
- Heating setpoints should remain the same or be reduced during GTA mode.

Auto-DR in 130,000 ft² County Office Current Practice

Martinez, CA Office Building Electricity Use with and without AutoDR June 21, 2006







DR Field Tests from 2003, 2004 & 2005



GSA, Phillip Burton Federal Building

Federal (San Francisco)

Office

1,424,000 ft²

2,130 kW peak



GSA, Ronald Dellums Federal Building

Federal (Oakland)

Office

978,000 ft²

4,100 kW peak



GSA, National Archive & Record Admin.

Federal (San Bruno)

Archive storage

238,000 ft²

280 kW peak



US Postal Service San Jose PDC

Federal (San Jose)

Process, distribution

390,000 ft²

1,630 kW peak



Joe Serna Jr. Cal EPA Headquarters Building

State (Sacramento)

Office

950,000 ft²

1,990 kW peak



UC Santa Barbara Davidson Library

State (Santa Barbara)

Library


289,000 ft²

1,090 kW peak

BERKELEY LAB


Typical Power Densities

- California Commercial End-Use Survey (CEUS) and eleven field test buildings (Yin et al. 2010)
- The simulation results from DRQAT are lower than field test data and CEUS, likely due to the assumed lighting densities, HVAC system efficiencies and building envelope of the prototypical building model




Results using GTA (2003-2005)


Site name	Area (ft²)	Cooling Capacity (Tons)	Strategy Used	# Days of Testing	Climate Zone	Outside temperature at time of peak	Average shed (W/ft²)*	Peak shed (W/ft²)
GSA Oakland Federal Building	978,000	3,840	Global Temp Adjustment	4	3	88	0.30	1.10
Contra Costa County 2350 Arnold	131,000	240	Global Temp Adjustment	2	12	90	0.30	0.67
Contra Costa County 50 Douglas	90,000	240	Global Temp Adjustment	2	12	90	0.58	1.34
GSA Santa Rosa Federal Building	80,000	200	Global Temp Adjustment*	20	2	95	1.50	2.40
Sacramento County Building	80,000	180	Global Temp Adjustment*	3	12	70	0.75	1.00
Cisco	4,354,000	24,600	Global Temp Adjustment & other strategies	1	4	90	0.16	0.20
Echelon	75,000	4,800	Global Temp Adjustment & other strategies	2	4	90	0.89	111e3





Typical EMCS Graphical User Interface



GTA – Conceptual Implementation #1 (Absolute)











GTA – Conceptual Implementation #2 (Relative)



Global Temp Adjustment (Relative)

"Relax" each zone by <u>2</u> deg.F

DR Mode






Cost to Implement GTA


- Software only no hardware cost.
- Several (smaller) vendors already offer this feature at no extra cost.
 - Sold nationwide
- Remaining vendors can add GTA to standard product line at a low one-time cost.
- GTA can be added to existing buildings
 - Zone level DDC required
 - Programming cost \$2K \$10K per site



Comfort: 1.5 deg. F° Temperature Rise at GSA (39 zone average)



Comfort: Online Tennant Survey





LBNL DR Strategies Report

•DR Control Strategies for Commercial Buildings:

DR Strategy	Global Temperature Adjustment (GTA)								
Definition	Increase zone temperature setpoints for an entire facility.								
HVAC type	CAV, VAV systems. Cooling by central plant or package unit DX.								
System	EMCS must have DDC control to the zone level. EMCS must have								
applicability	Global Temp Adjustment feature.								
Sequence of	Increase zone temperature cooling setpoints globally throughout								
Operation (DR)	entire facility.								
	Zone temperature heating setpoints must remain unchanged or be								
	reduced.								
Power savings in:	Fans & Cooling systems								
Efficiency	Permanent increase in zone temperature setpoints for some zones								
potential	may be possible								
Rebound	Gradual ramp back to normal setpoints. Lock out chillers etc.								
Avoidance									
Caution	Occupant comfort. Zones will approach increased temperature								
	setpoints at different rates.								

Building Control Strategies Guide and Case Studies

A	cknowledge	ements	iii
E	xecutive Su	mmary	iv
1.		ction	
1.			
		ectives and Report Organization	
	1.2. Obj	ectives and Report Organization	2
		lding Operations and Energy Management	
		minologies and Concepts	
2.	Demand	Response Strategy Overview	7
	2.1. HV	AC System	7
		hting Systems	
		scellaneous Equipments	
		vanced Control Strategies	
	2.5. Stra	ntegies Used in Case Studies	. 12
3.	Demand	Response Strategy Detail	. 15
		AC Systems	
	3.1.1.	Global Temperature Adjustment.	15
	3.1.2.	Passive Thermal Mass Storage	
	3.1.3.	Duct Static Pressure Decrease	
	3.1.4.	Fan Variable Frequency Drive Limit	
	3.1.5.	Supply Air Temperature Increase	
	3.1.6.	Fan Quantity Reduction	
	3.1.7.	Cooling Valve Limit	. 23
	3.1.8.	Chilled Water Temperature Increase	. 24
	3.1.9.	Chiller Demand Limit	. 25
	3.1.10.	Chiller Quantity Reduction	. 26
	3.1.11.	Rebound Avoidance Strategies	
	3.2. Lig	hting Systems	. 28
	3.2.1.	Zone Switching	
	3.2.2.	Fixture/Lamp Switching	
	3.2.3.	Step Dimming	
	3.2.4.	Continuous Dimming	
		cellaneous Equipments	
	3.3.1.	Fountain pump	
	3.3.2.	Anti-sweat heater	
	3.3.3.	Electric vehicle charger	
	3.3.4.	Industrial process loads	
	3.3.5.	Cold storage	
	3.3.6.	Irrigation water pump	
		n-Component-Specific Strategies	
	3.4.1.	Demand Limit Strategy	
	3.4.2.	Signal-level Response Strategy	. 36





Precooling and Thermal Mass

Evaluate the Effect of Control Strategies based on:


- Utility rate structure
- Peak demand savings
- Zone comfort (PPD)

Pre-cooling with Linear Tempearature Set up











Pre-cooling with Exponential Tempearature Set up



Load Statistical Summary (LSS)

LSS a plot of average, minimum and maximum points for a given range of dates.

- Refined to display Near-base load and near-high load (2.5 and 97.5 percentile values) (Price 2010)



Fan System Adjustment - Fan speed limit

- Applicable to fans with variable frequency drives (VFDs).
- Similar to duct static pressure setpoint reduction.
- Less predictable because of the open-loop nature of the control.
- Fan speed limits may be useful as part of other DR strategies such as cooling system adjustments.



Fan System Adjustment - Fan Quantity Reduction.

- Applicable to constant air volume fan systems.
- Reduce fan energy by turning fans OFF completely.
- May be useful in common areas served by multiple fans.
- Cooling energy in the fans that remain ON may increase to make up for those that are OFF.



Fan System Adjustment – Increase Supply Air temperature

- Applicable to CAV and VAV fan systems
- Saves mechanical cooling energy
 - For air handlers with cooling coils, the savings will occur at the central cooling plant.
 - For packaged DX units & heat pumps, the savings will be achieved at each unit.

- Avoid increased fan energy in VAV systems due to increased air flow
 - Prevent this effect by limiting fan speeds to prior levels



Fan System Adjustment - Cooling System Adjustment

- Applicable to Central Chiller plants & Packaged DX units & Heat Pumps.
- Most modern centrifugal, screw and reciprocating chillers have the capability of reducing demand for power:
 - Raise chilled water supply temperature setpoint
 - Limit the speed, capacity, number of stages or current draw of the chiller
 - The quantity of chillers running can be reduced in some plants




Lighting Based DR Strategies

- Lighting systems offer great promise as a resource for DR shed savings
 - Lighting systems account for ~ 1/3 electric load in commercial buildings
 - Lighting has no rebound effect during the transition from DR events to normal operations
 - In California, most commercial buildings already have bi-level switching. 1/3 or 2/3 of the lights in a given office can be turn off.
 - Pre-planned automated DR strategies make sheds more repeatable and less labor intensive.
- Technical challenges:
 - Few office buildings have centralized control of lighting systems (Kiliccote, et al, 2005).
 - Buildings with centralized lighting controls are not necessarily zoned to enable reduced light levels adequate for occupancy.

Lighting Based DR Strategies

- Resolution of control is an important factor in determining the usefulness of lighting systems for DR. From highest to lowest resolution.
 - Continuous Dimming.
 - Allow light output to be dimmed from 100% to 10% (fluorescent) or 100% to 50% (HID).
 - Gradual reductions not noticeable
 - specific DR shed goals can be achieved
 - Energy efficiency benefits in addition to DR
 - Stepped Dimming, Lamp Switching, and Fixture Switching
 - 2 or 3 light levels
 - Noticeable, but manageable light levels.
 - Lighting zones must be wired to ensure that all floor space remains illuminated at reduced levels.
 - Zone Switching
 - Applicable to zones that are unoccupied, or illuminated by windows.
 - Egress light levels must be assured.


DR Strategies: Lighting (of)




Comparison of End-Use Strategies

		Λ																		
Clabal tamman	0.4	HV	AC										Lig	htin	g			Oth	ner	
reset migrated State Energy C	to	Global temp. adjustment	Duct static pres. ₃	SAT Increase	Fan VFD limit	CHW temp. Increase	Fan qty. reduction	Pre-cooling	Cooling valve limit	Boiler lockout	Slow recovery	Extended shed period	Common area light dim	Office area light dim	Turn off light	Dimmable ballast	Bi-level switching	Non-critical process shed		
ACWD	Building use Office, lab	X	X	X	ш_	X	ш.	Δ.	X	X	(C)	Х	0	0			<u> </u>	_	1	
B of A	Office, data center		X	X	Х	X			X										1	
Chabot	Museum	Х						Х											1	
2530 Arnold	Office	X									X								•	
50 Douglas	Office	X									X								1	
MDF	Detention facility	X									, ,								•	
Echelon	Hi-tech office	X	X	Х			Х						Х	Х	Х	Χ			1	
Centerville	Junior Highschool	X	Ť	, ,				Х					, ,	, ,					1	
Irvington	Highschool	X						X											-	
Gilead 300	Office			Х															1	
Gilead 342	Office, Lab	Х		Х															1	
Gilead 357	Office, Lab	Х		Х															1	
IKEA EPaloAlto	Furniture retail	Х																	1	
IKEA Emeryville	Furniture retail	Х																	1	
IKEA WSacto	Furniture retail																		1	
Oracle Rocklin	Office	Х	X																1	
Safeway Stockton	Supermarket																Χ		1	
Solectron	Office, Manufacture	Х													Х				1	
Svenhard's	Bakery																	Х	_	
Sybase	Hi-tech office														Х				-	
Target Antioch	Retai	Х					Х													
Target Bakersfield	Retail	Х					Χ												LLLL	
Target Hayward	Retail	Х					Х						Х				Х			
Walmart Fresno	Retail	Х															Χ			J
																	BE	ERK	ELEY LAB	

Global Temperature Adjustment




Aggregated AutoDR Results - June 26, Zone 2




	Avera	ge kW	Avera	age %	Average W/ft ²			
	Moderate	High	Moderate	High	Moderate	High		
ACWD	78	91	28%	32%	1.53	1.78		
B of A	478	604	9%	12%	0.67	0.85		
2530 Arnold	102	140	20%	29%	0.78	1.07		
50 Douglas	57	94	13%	22%	0.63	1.04		
MDF	90	155	17%	30%	0.52	0.90		
Echelon	-2	80	0%	22%	-0.02	1.07		
Oracle Rocklin	85	60	17%	14%	0.85	0.60		
Target Hayward	59	56	15%	15%	0.45	0.43		
Aggregated	946	1281	11%	16%	0.65	0.88		

Consistent Multi-Year Field Performance Automating DR


OpenADR Application Impacts 2003-2009






BERKELEY

Cumulative Shed on 7/9/08



Demand Profiles from Test Events


SMT Test_1, 3/3/2009 (Min OAT: 43 °F)



Technical Coordination Concept - Automation

- Initially hand-holding customers through the automation process including DR strategy development and technology integration done by LBNL researchers.
- Identified as an important role for successful commercialization.
- Control vendors identified as ideal candidates.
- Tested with the Demand Response Integration Services Company (DRISCO) concept in 2006
- Utilized in 2007 Auto-DR (Hands-on vs. Hands-off)

DR Enablement Process



Historical data used for various purposes:

- 1. Visual analysis
- 2. Develop Load Statistical Summary
- 3. Evaluate Load Variability and Weather Sensitivity Collect information on end uses, systems, controls and operations


What kind of DR program works for the facility? Mapping load shapes onto rates and programs

Semi- or fully-automated

Calculate shed - is it acceptable? Variable?




Installation and TC Costs for 2007 AutoDR



Demand Side Management and Automated DR Future






Increasing Levels of Granularity of Control Increasing Speed of Telemetry




Linking DR and Energy Efficiency

- **Ideal start** good commissioning, retrocommissioning, advanced/new controls
 - **HVAC** Direct digital control (DDC) global temperature adjustment
 - In process for California Building Code
 - Closed loop
 - **Lighting Continuum** Zone Switching, Fixture Switching, Lamp Switching, Stepped Dimming, Continuous Dimming
 - Maybe you "can" use a strategy every day?



Parameters for Evaluating Load Shapes – also useful for Retro-commissioning

- Near-Base Load (kW): 2.5th percentile of daily load.
- Near-Peak Load (kW): 97.5th percentile of daily load.
- High-Load Duration (Hours):
 Duration for which load is closer
 to near-peak load than to near-base load.
- Rise Time (Hours): Duration for load to go from near-base load to the start of the high-load period.
- Fall Time (Hours): Duration for the load to go from the end of the high-load period to the nearbase load.






Future Directions DR strategies as a "Modes" in Optimized Control


- Orchestrate modes using schedules, signals, optimization algorithms:
 - Occupied/Unoccupied
 - Maintenance/Cleaning
 - Warm up/Cool down
 - Night purge/Pre-cooling
 - Low power DR mode
- Intelligence needed for decision making
- Financial feedback systems need to present operational value
- Embed DR communications client in EMCS work toward codes, support BACnet and LON interoperability

See http://drrc.lbl.gov/ for publications





Summary of EIS State of Technology





Potential Collaboration – Web-Based Energy Information Systems

Problem Optimal energy performance requires high quality, granular building performance data, more timely analysis than monthly utility bills

Data Information Action

Projects

- 1. Review of Energy Information Systems (CEC Funded, complete)
- Defined a characterization framework
- Evaluated state of the technology 30 EIS
- Conducted user case studies to identify energy savings
- 2. Handbook on Energy Information Applications (DOE Funded, underway)
- Technical Advisory Group to select key applications
- Evaluated state of the technology
- Conducted user case studies to identify energy savings



Results and Next Steps

- Shown how key owners use EISneed to disseminate best practices and accelerate adoption
- Strong interest in movement toward utility incentives, developing specification for DOE Commerical Building Energy Alliances.
- Partnering/interest from vendors, Consortium for Energy Efficiency, USGBC, Utilities, ASHRAE Standard
- Web site: eis.lbl.gov

